



# Top Mount T-Handle UHMW Polyethylene Tape Retrofit

page 1 of 3



1. Using a small flathead screwdriver, remove the label from the top of the T-handle. Be careful not to damage the chrome that will be visible after the repair is complete.



2. Using a Goof-Off or Goo-Gone adhesive solvent, remove all of the adhesive residue from the label recess.



3. Using a metric allen wrench, loosen the flat head screw at the center of the handle. Be very careful while removing the handle so as not to lose the springs that load the handle.



4. Remove the two springs and keep them in a safe place.



## Top Mount T-Handle UHMW Polyethylene Tape Retrofit

page 2 of 3



5. Clean and wipe the outer surface of the T-handle base with isopropyl alcohol or equivalent.



6. Remove liner from 1 of 2 pieces of polyethylene tape. Install onto base as shown - flush with top edge. Press down firmly or burnish to ensure good adhesion.



7. Using second piece of ultra high molecular weight polyethylene tape, repeat step 6 on other side of T-handle base.



8. Carefully replace both screws making sure they are seated into the cast-in recesses.



# Top Mount T-Handle UHMW Polyethylene Tape Retrofit

page 3 of 3



9. Place the T-handle cap back onto the assembly being very careful to seat the top of the springs into the recesses on the underside of the casting. This can be difficult at first.



10. Making sure that the springs are present and properly seated, tighten the screw until it stops. An extra screw has been provided in case the original was stripped during removal.



11. Clean and wipe the label recess with isopropyl alcohol or equivalent.



12. Carefully install the new oval verbiage tag provided.